Wireless Keyboard User Manual

Thank you for purchasing this product. Please read the instructions carefully before use and pay particular attention to the specially marked notes.

PAIRING INSTRUCTIONS { Turn on the keyboard and hold "Fn" + "1" for 3 seconds until Connection Indicator 1 flashes quickly.
Turn on Bluetooth on your device and connect to "WirelessKeyboard 1".

{ Turn on the keyboard and hold "Fn" + "2" for 3 seconds until Connection Indicator 2 flashes quickly
Turn on Bluetooth on your device and connect to "WirelessKeyboard 2".

To switch between devices, simply press "Fn" and "1" or "2".



FN+Tab:
Show/hide the virtual keyboard

*** This feature is important:
FN+ Lock/unlock keyboard input;
The keys do not function when locked.
This prevents them from being accidentally pressed.

Use the "Fn" key with the blue characters/functions.

FN + Space bar: ESC function

*** The keyboard layout in this diagram is based on the US keyboard and is for reference only. Actual keyboard may vary. ***

Disconnecting the Keyboard:

- To disconnect the keyboard, either delete it from the list of paired Bluetooth devices on your device or turn it off.

Battery Indicator:

- If the battery indicator is flashing slowly, the keyboard is low on battery. Please charge it. The indicator will light up red while charging and turn green when the keyboard is fully charged. Please remove the charging cable when charging is complete.



Technical Specifications:

(Some values will vary during use due to environmental factors)

Operating Voltage	3.0-4.2 V	Pairing Password	None
Use Time	≥80 hours	Operating Current	≤3.0 mA
Sleep Current	≤0.3 mA	Low Voltage Alert	3.0-3.3 V
Battery Capacity	180 mAh	Charging Input	5 V, 500 mA
Operating Range	10 m	Charging Time	2-3 hours
Charging Current	150-300 mA	Wake-Up Time	2-3 seconds
Charging Port	USB-C	Operating Temperature	-10°C-+55°C

*** Note: if "WirelessKeyboard 1/2" does not show up on your device, please turn Bluetooth off on your device first, then turn it on again and search for the keyboard once more. If necessary, delete all previously paired Bluetooth devices from your device, re-start it and then follow the pairing instructions once again.

Maintenance and Warning:

- Do not crush, bend or knock the keyboard.
- Do not scan the keyboard with microwaves and keep it away from magnetic fields.
- Keep the keyboard away from liquids and use in a dry environment.
- Clean the keyboard with a soft cloth.
- Do not simply throw away the keyboard. Make sure to recycle it according to the rules of your local jurisdiction.

Troubleshooting:

- Make sure the keyboard is turned on and the battery is sufficiently charged.
- If the keyboard does not charge after multiple attempts, try different charging cables.
- Make sure the keyboard is within operating range.
- Make sure Bluetooth is turned on on your device.
- Make sure the keyboard and your device are paired and connected.
- Delete all previously paired Bluetooth devices from your device and turn off Bluetooth, then try to re-pair the keyboard with your device. If necessary, re-start your device.
- Do not pair and connect multiple Bluetooth keyboards at the same time; if necessary, please connect them one at a time.